
Signals
Light Left
US
US
Light Driver
Light Driver
US
US
Light Right
Motor FL
ENC
Front Left
H bridge FL
H bridge FR
ENC
Motor FR
Front Right
dsNav Front master
High Level Supervisor
GPS
MAG
IMU
Sonar Board
Out-Of-Band Monitor
PWR Left
7V Reg
Battery Left
TMP
Battery Right
TMP
PWR Right
7V Reg
Low Level Supervisor
7V Reg
dsNav Back slave
H bridge BL
H bridge BR
Motor BL
ENC
Back Left
OFF
ON
ENC
Motor BR
Back Right